

# G250R

## INSTALLATION GUIDE

The G250R is a 1" wide semi-rigid strip with a 3M foam tape on the base. The G250R is a highly visible strip to fit a range of photoluminescent pathway marking applications. The rigidity of the strip, the thickness of the foam tape and the strength of the adhesive allows the G250R to effectively be installed on many different surfaces.

**NOTE:** It is recommended that the G250R is installed on the wall instead of the floor whenever possible.


### Required Tools:

- Rubbing Alcohol or Acetone
- Roller
- Brush and Pan
- Paint Scraper
- Soft Cloth
- Scissors or hand shears
- Pencil

### 1. Preparation of Surface

Ensure the mounting Surface is dry and clean of dirt, dust and debris.

**NOTE:** If the installation surface is questionable, we recommend installing a test piece.



### 2. Application Method

- Place the G250R Ecoglo strip in the installation location to check if the G250R needs to be cut to a smaller size. If the product needs to be cut to a shorter length, use a pencil to mark the cutting location. Cut the G250R using hand shears or a good pair of scissors.
- Lay the Ecoglo strips upside down and remove the paper adhesive from the underside of the strip.
- Starting at one end, apply the G250R to the installation surface, ensure it is applied level.
- Apply pressure using a roller to ensure a good bond along its full length.