

# G250R-H PHOTOLUMINESCENT HANDRAIL STRIP INSTALLATION GUIDE

The G250R-H is a curved 1" wide semi-rigid strip with an aggressive 3M tape on the base. The rigidity of the strip and strength of the adhesive allows the G250R to effectively be installed on round handrails.

## Required Tools:

- Rubbing Alcohol or Acetone
- Roller
- Soft Cloth
- Scissors or hand shears
- Corner Cutters (Provided by Ecoglo)
- Pencil



## 1. Preparation of Surface

- Ensure the mounting Surface is dry and clean of dirt, dust and debris.



## 2. Preparing the Strip for Installation

- Place the G250R-H Ecoglo strip in the installation location to check if the G250R-H needs to be cut to a smaller size. If the product needs to be cut to a shorter length, use a pencil to mark the cutting location. Cut the G250R-H using hand shears or a good pair of scissors.
- When pieces are being joined together to make a longer length, ensure that straight cuts are made and that the strips line up cleanly.
- For ends that are not being joined, use the corner cutter to cut round corners at the end of the section.

## 3. Application Method

- Lay the G250R-H strips upside down and remove the paper adhesive from the underside of the strip.
- Starting at one end, apply the G250R-H to the installation surface and ensure it is applied in a straight line directly on the top of the handrail.
- Apply pressure using a roller to ensure a good bond along its full length.

## NOTE:

The G250R-H handrail strips should not be installed on sections of handrails that are bent. The G250R-H should end right before the bend begins and another strip of G250R-H should start on the other side of the bend.