



C Series Installation Guide

Preparation of Surface

- You should not install Ecoglo nosings over the top of carpet.
- Remove the carpet from the edge of the strip and fix the nosing with adhesive and mechanical fixers to the substrate below.
- The carpet nosing is designed to aid in the replacement of your carpet.



Cutting Away Carpet

- Place the nosing firmly against the riser of the step.
- Release the nosing approximately 3/8ths of an inch.
- Using a sharp box-cutter type knife cut the carpet parallel to the nosing around all three sides.



- Remove the nosing and cut along the leading edge of the step.
- Remove the carpet and place the nosing firmly against the riser of the step.
- Line it up with your string line and mark the location of the drill holes.



- Using a 1/4 inch masonry bit, drill the hole that will house the plastic anchor.
- Wipe away any dust or debris
- Thoroughly clean the surface with an industrial strength cleaner.
- Remove any paint or sealant
- Allow the surface to dry
- Place the anchor firmly into the holes



- Lay a 1/8 inch bead in a wave pattern over the full length of the underside of the nosing.
- Keep the adhesive clear of the outside edge and the drill holes.
- **Note:** *Ecoglo New Zealand installations use Bostik Seal n Flex FC. Expected usage of adhesive is: 22 metres per 600ml sausage.*



- Place the nosing firmly back onto the step, lining up the drill holes.
- Tighten the screws firmly - this will create a strong, even bond.

