



F Series Installation Guide

Preparation of Surface

- Thoroughly clean the surface with an industrial cleaner.
- Remove any paint or sealant and then allow the surface to dry



Alignment (for installation to more than one step)

- Place one piece of step nosing on the top step and one on the bottom step.
- Run a string line from the left edge of the top nosing to the left edge of the bottom nosing.
- This will give you a straight, true line.
- **NOTE:** *The maximum recommended length for installation in outdoor situations is 1.5 metres, with a minimum 5mm gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.*



- Place the nosing firmly against the riser of the step.
- Line it up with your string line
- Mark the location of the drill holes
- Using a 1/4 inch masonry bit, drill the hole that will house the plastic anchor



- Wipe away any dust or debris
- Place the plastic anchor fully in to the holes



- Lay a 1/8 inch bead in a wave pattern over the full length of the underside of the nosing.
- Keep the adhesive clear of the outside edge and the drill holes.





- Place the nosing firmly back onto the step, lining up the drill holes.
- Tighten the screws firmly - this will create a strong, even bond.

