



# **C Series Installation Guide**

# Tools Required

- Acetone cleaner
- Glue gun
- Bostik 1100 FS Urethane Adhesive
- Roller
- Brush and pan
- Paint scraper
- Soft cloth
- Hammer drill
- Concrete Screws
  - # 8 x 32mm (1 ¼ inch) countersunk square (#1) Stainless Steel AB self tapping screw, Phillips drive.
- Anchor – 6mm x 30mm (0.25 x 1 3/16 inches) plastic anchor
- 6 mm masonry drill bits



# Preparation of Surface

- You should not install Ecoglo nosings over the top of carpet.
- Remove the carpet from the edge of the strip and attach the nosing with adhesive and mechanical fasteners to the substrate below.
- The carpet nosing is designed to aid in the replacement of your carpet.



# Cutting Away Carpet

- Place the nosing firmly against the riser of the step.
- Release the nosing approximately 10mm (3/8ths of an inch).
- Using a sharp box-cutter type knife cut the carpet parallel to the nosing around all three sides.



- Remove the nosing and cut along the leading edge of the step.
- Remove the carpet and place the nosing firmly against the riser of the step.
- Line it up with your string line and mark the location of the drill holes.



- Using a 6mm (1/4 inch) masonry bit, drill the hole that will house the plastic anchor.
- Wipe away any dust or debris
- Thoroughly clean the surface with an industrial strength cleaner.
- Remove any paint or sealant
- Allow the surface to dry
- Place the anchor firmly into the holes



- Lay a 3mm (1/8 inch) bead in a wave pattern over the full length of the underside of the nosing.
- Keep the adhesive clear of the outside edge and the drill holes.
- **Note:** For *Bostik 1100 FS* Expected usage of adhesive is: 22 metres (72ft, 2 inches) per 600ml cartridge.



- Place the nosing firmly back onto the step, lining up the drill holes.
- Tighten the screws firmly - this will create a strong, even bond.

