



On-Site Cutting Guide



Measuring the Nosing

- Measure the required length of the nosing and the insert.
- Mark the position on both pieces where you will cut.



Cutting The Aluminum Nosing To Length

- Use a circular saw with a suitable tungsten carbide tip blade.
- Cut the nosing at the length measured.
- **NOTE:** *The maximum recommended length for installation in outdoor situations is 1.5 metres, with a minimum 5mm gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.*



Cutting The Insert To Length

- Non-slip inserts contain silicon carbide grit that rapidly blunt high-speed saw blades, so a manual guillotine (as pictured) is needed to cut the insert.
- Lay the insert strip, upside down, into the pre-cut nosing. Mark the insert strip for cutting.
- Remove the insert strip from the nosing and place into the guillotine. Use the guillotine to cut the insert.



Installing the Insert Strip Into the Nosing

For Exposed Fixings

- Wipe away any dust or debris from the nosing channel.
- Remove the backing paper from the double sided tape.
- Press the insert firmly in place to ensure even contact between the adhesive tape and the surface of the channel, using a roller or your hand.

