




VISIBLY BETTER

G250R-H Photoluminescent Handrail Strip **Installation Instructions**

The G250R-H is a curved 1" wide semi-rigid strip with an aggressive 3M tape on the base. The rigidity of the strip and strength of the adhesive allows the G250R to effectively be installed on round handrails.

Tools Required

- Rubbing Alcohol or Acetone
- Roller
- Soft Cloth
- Scissors or hand shears
- Corner Cutters (Provided by Ecoglo)
- Pencil



Installation procedure

- Ensure the mounting Surface is dry and clean of dirt, dust and debris.
- Place the G250R-H Ecoglo strip in the installation location to check if the G250R-H needs to be cut to a smaller size. If the product needs to be cut to a shorter length, use a pencil to mark the cutting location. Cut the G250R-H using hand shears or a good pair of scissors.
- When pieces are being joined together to make a longer length, ensure that straight cuts are made and that the strips line up cleanly.
- For ends that are not being joined, use the corner cutter to cut round corners at the end of the section.
- Lay the G250R-H strips upside down and remove the paper adhesive from the underside of the strip.
- Starting at one end, apply the G250R-H to the installation surface and ensure it is applied in a straight line directly on the top of the handrail.
- Apply pressure using a roller to ensure a good bond along its full length.

Note: The G250R-H handrail strips should not be installed on sections of handrails that are bent. The G250R-H should end right before the bend begins and another strip of G250R-H should start on the other side of the bend.

ECOGLO INC.
241 Main St., Suite 100 Buffalo, New York 14203
Tel (888) 679-4022 Fax (877) 679-4022
www.us.ecoglo.com