

G SERIES INSTALLATION GUIDE WITH FASTENERS

Required Tools:

- Rubbing Alcohol or Acetone
- Premium Polyurethane adhesive/sealant
*Bostik 915 or Bostik 110 are recommended
- Caulking gun
- Roller
- Brush and Pan
- Paint Scraper
- Soft Cloth
- Box Cutter
- Painters tape
- Concrete Screws:# 8 x 32mm (1 ¼ inch) countersunk square (#1) Stainless Steel AB self tapping screw, Phillips drive.
- Anchors – 6mm x 30mm (0.25 x 1 3/16 inches) plastic anchor
- 6 mm masonry drill bits

1. Preparation of Surface

- Ensure the mounting Surface is clean of dirt, dust and debris.

Note: vlf a sealant has been applied to the concrete, we recommend contacting your local adhesive representative to check compatibility.

2. Drilling the Substrate

- Place the strips down at their final installation location and mark the drilling locations through the pre-drilled holes that are in the strips.
- Remove the strips and using a 6mm (1/4 inch) masonry bit, drill the hole at the marked locations that will house the plastic anchor.

3. Inserting Anchors

- Vacuum away any dust or debris
- Place the anchor firmly into the holes

4. Prepare for Adhesive

- Lay the Ecoglo strips upside down and clean off any possible residue from the underside.
- Thoroughly clean the surface with an industrial strength cleaner.
- Remove any paint or sealant
- Allow the surface to dry



5. Applying Adhesive

- Using a caulking gun apply a 2mm bead of the recommended polyurethane adhesive along the full length of the underside of the strip.
- Keep the adhesive clear of the outside edge and the drill holes.

Note: Expected usage of adhesive is 50 feet per 10.2 Oz tube.



6. Securing the Strip

- Turn the Ecoglo strip back to the right side up and press onto the surface.
- Apply downward pressure using a roller to ensure a good bond along its full length.
- If any adhesive squeezes out around the edges, wait until it cures before removing by trimming off with a box-cutter type of cutting blade.
- Fasten the screws into the concrete nylon anchors through the pre-drilled holes.
- Wipe away any dust from the strip

