

T SERIES GUIDANCE STRIP INSTALLATION GUIDE

THRESHOLD STRIP

Required Tools:

- Measuring tape
- Level
- Cutting table
- Chop saw
- File tool
- Drill and countersink (Countersunk No. 4, 82 Degrees)
- Hammer drill
- (Provided) concrete screws and anchors
- Hammer
- Phillips screwdriver
- Broom and dustpan
- Rubber roller

1. Preparation of Surface

- Ensure the mounting surface is clean of dirt, dust and debris.
- If a sealant has been applied to the concrete steps we recommend contacting your local adhesive representative to check compatibility.



2. Alignment (for installation to more than one step)

- Place one piece of step nosing on the top step and one on the bottom step.
- Run a string line from the left edge of the top nosing to the left edge of the bottom nosing.
- This will give you a straight, true line

NOTE: The maximum recommended length for installation in outdoor situations is 1.5 metres (5 foot), with a minimum 5mm (1/5th inch) gap between lengths. This allows for thermal expansion in extreme weather conditions and also aids in water drainage off the step tread.



3. Apply Adhesive

- Using a cartridge glue gun apply a 3mm (1/8 inch) bead of the recommended polyurethane adhesive in a weaving pattern along the full length of the underside of the nosing.

NOTE: Ecoglo New Zealand installations use Bostik Seal n Flex FC. (US equivalent: Bostik 1100 FS) Expected usage of adhesive is: 28 metres (92 foot) per 600ml sausage.



4. Placement of Strip

- Turn the Ecoglo strip back to right side up and press on to the step.
- Apply downward pressure to ensure a good bond along its full length.
- If any adhesive squeezes out around the edges, wait until it cures before removing by trimming off with a box-cutter type cutting blade.
- Immediately following installation close off the area for a period of 2-3 hours to avoid the Ecoglo strip being moved whilst the adhesive is in the early stages of "cure".

